

33626 LOGI 02-1100-142 cm

Shutter Switch



A roller blind switch is used to control power supply systems of external roller blinds. The switch comes with two buttons for moving roller blinds up and down. The switch has a system that makes it impossible to press both buttons at the same time. A bistable switch maintains the position, i.e. it does not go back to the previous position after pressing.

GENERAL DATA:

Colour: black matt

Place of assembly: Recessed mount in the wall

Highlighting: no

Width [mm]: 71

Height [mm]: 71

Diameter of an installation box: 60

Installation depth: 25

TECHNICAL DATA:

Rated voltage [V]: 250 AC

Material of contacts: CuZn70

Terminal type: Screw terminal

Plastic: ABS

Number of levers: 2

Rated current [AX]: 10

IP class: 20

