

## KCS

### Installationsschalter



KCS-40A/1P



|            |              |            |   |
|------------|--------------|------------|---|
| KCS-40A/1P | <b>23255</b> | 230/400 AC | 1 |
| KCS-40A/2P | <b>23256</b> | 230/400 AC | 2 |
| KCS-40A/3P | <b>23257</b> | 230/400 AC | 3 |
| KCS-40A/4P | <b>23258</b> | 230/400 AC | 4 |
| KCS-63A/1P | <b>39400</b> | 230/400 AC | 1 |
| KCS-63A/2P | <b>39401</b> | 230/400 AC | 2 |
| KCS-63A/3P | <b>39402</b> | 230/400 AC | 3 |
| KCS-63A/4P | <b>39403</b> | 230/400 AC | 4 |

## KCS

### Installationsschalter



KCS-40A/1P



KCS-40A/2P



KCS-40A/3P



KCS-40A/4P



KCS-63A/1P




KCS-63A/2P




KCS-63A/3P




KCS-63A/4P




KCS-40A/1P



KCS-40A/2P




KCS-40A/3P




KCS-40A/4P

## KCS


### Installationsschalter




KCS-63A/1P



KCS-63A/2P



KCS-63A/3P



KCS-63A/4P