

## KTB

Распределительная коробка



KTB-100-7



		[V]	In [A]
KTB-100-7	<b>23330</b>	500 AC	100
KTB-100-15	<b>23331</b>	500 AC	100
KTB-125-1	<b>23332</b>	1000 AC	125
KTB-125-15-M	<b>23333</b>	500 AC	125
KTB-125-7-M	<b>23334</b>	500 AC	125
KTB-125-1-M	<b>23335</b>	690 AC	125



KTB-100-7



KTB-100-15



KTB-125-1



KTB-125-15-M

## КТВ


### Распределительная коробка




KTB-125-7-M




KTB-125-1-M




KTB-100-7




KTB-100-15




KTB-125-1



KTB-125-15-M



KTB-125-7-M



KTB-125-1-M