

## BIURO+

### Підлогова коробка

<b>[V]</b> 250 AC	<b>[Hz]</b> 50/60	<b>In[A]</b> 16	 12		<b>IP</b> 20	
<b>CE</b>		<b>EAC</b>				



BIURO+ 04-0011-100



BIURO+ 04-0011-100	<b>28300</b>	антрацит
BIURO+ 04-0012-100	<b>28301</b>	нержавіюча сталь
BIURO+ 04-0013-100	<b>28302</b>	наповнити



BIURO+ 04-0011-100



BIURO+ 04-0012-100




BIURO+ 04-0013-100


## BIURO+

---


### Підлогова коробка



BIURO+ 04-0011-100



BIURO+ 04-0012-100



BIURO+ 04-0013-100