

## 25190 LOGI 02-1030-143 sr

Bell push switch

5905339251909



A doorbell switch is used to control mechanisms of doorbell relays. It does not have a symbol on the button.

### PRODUCT PARAMETERS:

**Colour:** silver

**Place of assembly:** Recessed mount in the wall

**Highlighting:** yes

**Width [mm]:** 71

**Height [mm]:** 71

**Diameter of an installation box:** 60

**Installation depth:** 25

**Rated voltage [V]:** 250 AC

**Material of contacts:** CuZn70

**Terminal type:** Screw terminal

**Plastic:** ABS

**Number of levers:** 1

**Rated current [AX]:** 10

**IP class:** 20

### LOGISTIC DATA:

**Packaging method:** 10

**Number of units in the secondary packaging:** 10

**Number of units in the packaging:** 120

**Net unit weight [g]:** 72

**Grammage [g]:** 84.33

**Length of a unit pack [cm]:** 9

**Width of a unit pack [cm]:** 5

**Height of a unit pack [cm]:** 14


**Weight of a cardboard box [kg]:** 10.1196

**Width of a cardboard box [cm]:** 25.5

**Height of a cardboard box [cm]:** 32

**Length of a cardboard box [cm]:** 44

**Volume of a cardboard box [m³]:** 0.035904





by **Kanlux** ul. Objazdowa 1-3, 41-922 Radzionków, Poland

## **25190** LOGI 02-1030-143 sr

---

Bell push switch