


## 33234 TEAR N PCON R-W

Power connection

5905339332349



### PRODUCT PARAMETERS:

**Colour:** white

**Place of assembly:** rail TEAR

**Place of application:** Indoors

**Rated voltage [V]:** 220-240 AC

**Rated current [A]:** 16

**Rated frequency [Hz]:** 50

**Class of protection against electric shock:** I

**Ambient temperature range to which the product can be exposed:** 5÷25

**Enclosure material:** plastic

**IP class:** 20

### LOGISTIC DATA:

**Packaging method:** 50

**Number of units in the secondary packaging:** 1

**Number of units in the packaging:** 50

**Net unit weight [g]:** 56

**Grammage [g]:** 64

**Length of a unit pack [cm]:** 8

**Width of a unit pack [cm]:** 3.5

**Height of a unit pack [cm]:** 18

**Weight of a cardboard box [kg]:** 3.2

**Width of a cardboard box [cm]:** 17.5

**Height of a cardboard box [cm]:** 21

**Length of a cardboard box [cm]:** 29

**Volume of a cardboard box [m³]:** 0.010658

### ADDITIONAL INFORMATION:

- Power connector with R plug designed to connect the power supply to the track.

### ACCESSORIES:

**33230** TEAR N TR 1M-W



Track system component, TEAR N TR 1M-W, 3-circuit track, white, (33230)

**33231** TEAR N TR 1M-B

Track system component, TEAR N TR 1M-B, 3-circuit track, black, (33231)

## 33234 TEAR N PCON R-W

### Power connection



**33232** TEAR N TR 2M-W

Track system component, TEAR N TR 2M-W, 3-circuit track, white, (33232)



**33233** TEAR N TR 2M-B

Track system component, TEAR N TR 2M-B, 3-circuit track, black, (33233)



**33234** TEAR N PCON R-W

Track system component, TEAR N PCON R-W, power connector with plug R , white, (33234)



**33235** TEAR N PCON R-B

Track system component, TEAR N PCON R-B, power connector with plug R , black, (33235)



**33260** TEAR N PCON L-W

Track system component, TEAR N PCON L-W, power connector with plug L, white, (33260)



## 33234 TEAR N PCON R-W

### Power connection

**33261** TEAR N PCON L-B Track system component, TEAR N PCON L-B, power connector with plug L, black, (33261)



**33236** TEAR N EPLUG W Track system component, TEAR N EPLUG W, end plug, white, (33236)



**33237** TEAR N EPLUG B Track system component, TEAR N EPLUG B, end cap, black, (33237)



**33238** TEAR N ICON-I W Track system component, TEAR N ICON-I W, straight connector type "I" internal with plugs L, R, white, (33238)



**33239** TEAR N ICON-I B Track system component, TEAR N ICON-I B, straight connector type "I" internal with plugs L, R, black, (33239)



**33240** TEAR N CON-I W Track system component, TEAR N CON-I W, straight connector type "I" with plugs L, R, white, (33240)



## 33234 TEAR N PCON R-W

### Power connection

<b>33241</b>	<b>TEAR N CON-I B</b>	Track system component, TEAR N CON-I B, straight connector type "I" with plugs L, R, black, (33241)
		
<b>33252</b>	<b>TEAR N CON-I FLEX W</b>	Track system component, TEAR N CON-I FLEX W, flexible connector with plugs L, R, white, (33252)
		
<b>33253</b>	<b>TEAR N CON-I FLEX B</b>	Track system component, TEAR N CON-I FLEX B, flexible connector with plugs L, R, black, (33253)
		
<b>33242</b>	<b>TEAR N CON-L RL-W</b>	Track system component, TEAR N CON-L RL-W, corner connector type "L" with plugs R, L, white, (33242)
		
<b>33243</b>	<b>TEAR N CON-L RL-B</b>	Track system component, TEAR N CON-L RL-B, corner connector type "L" with plugs R, L, black, (33243)
		
<b>33244</b>	<b>TEAR N CON-L LR-W</b>	Track system component, TEAR N CON-L LR-W, corner connector type "L" with plugs L, R, white, (33244)
		

## 33234 TEAR N PCON R-W

### Power connection

<b>33245</b>	TEAR N CON-L LR-B	Track system component, TEAR N CON-L LR-B, corner connector type "L" with plugs L, R, black, (33245)
		
<b>33246</b>	TEAR N CON-X W	Track system component, TEAR N CON-X W, cross connector with plugs L, L, R, R, white, (33246)
		
<b>33247</b>	TEAR N CON-X B	Track system component, TEAR N CON-X B, cross connector with plugs L, L, R, R, black, (33247)
		
<b>33248</b>	TEAR N CON-T RRL-W	Track system component, TEAR N CON-T RRL-W, connector type "T" with plugs R, R, L, white, (33248)
		
<b>33249</b>	TEAR N CON-T RRL-B	Track system component, TEAR N CON-T RRL-B, connector type "T" with plugs R, R, L, black, (33249)
		
<b>33250</b>	TEAR N CON-T RLL-W	Track system component, TEAR N CON-T RLL-W, connector type "T" with plugs R, L, L, white, (33250)
		

## 33234 TEAR N PCON R-W

### Power connection

<b>33251</b>	TEAR N CON-T RLL-B	Track system component, TEAR N CON-T RLL-B, connector type "T" with plugs R, L, L, black, (33251)
		
<b>33262</b>	TEAR N CON-T LRR-W	Track system component, TEAR N CON-T LRR-W, connector type "T" with plugs L, R, R, white, (33262)
		
<b>33263</b>	TEAR N CON-T LRR-B	Track system component, TEAR N CON-T LRR-B, connector type "T" with plugs L, R, R, black, (33263)
		
<b>33264</b>	TEAR N CON-T LLR-W	Track system component, TEAR N CON-T LLR-W, connector type "T" with plugs L, L, R, white, (33264)
		
<b>33265</b>	TEAR N CON-T LLR-B	Track system component, TEAR N CON-T LLR-B, connector type "T" with plugs L, L, R, black, (33265)
		
<b>33256</b>	TEAR N SKIT W	Track system component, TEAR N SKIT W, suspension with self-regulation and cord 2m, white, (33256)
		

## 33234 TEAR N PCON R-W

---

### Power connection

#### 33257 TEAR N SKIT B



Track system component, TEAR N SKIT B, suspension with self-regulation and cord 2m, black, (33257)

#### 33254 TEAR N SCLAMP W



Track system component, TEAR N SCLAMP W, mounting/stiffening suspension clamp, white, (33254)

#### 33255 TEAR N SCLAMP B



Track system component, TEAR N SCLAMP B, mounting/stiffening suspension clamp, black, (33255)